

## Kitset Planter Boxes 1200mm Wide x 400mm High

Planter Size Height = 400mm Width x Length	Width	No.	Length	No.	Mid		Total Metres	Coach Screws		Total	m3 or tonne
					Brace	No.		&Washer m10x150	Multigrip		
1200x600x400	1.0	4	0.6	4	1.0	0	6.4	16	4	\$333	0.128
1200x900x400	1.0	4	0.9	4	1.0	0	7.6	16	4	\$366	0.152
1200x1200x400	1.0	4	1.2	4	1.0	0	8.8	16	4	\$399	0.176
1200x1500x400	1.0	4	1.5	4	1.0	0	10.0	16	4	\$432	0.200
1200x1800x400	1.0	4	1.8	4	1.0	0	11.2	16	4	\$466	0.224
1200x2100x400	1.0	4	2.1	4	1.0	0	12.4	16	4	\$499	0.248
1200x2400x400	1.0	4	2.4	4	1.0	0	13.6	16	4	\$532	0.272
1200x2700x400	1.0	4	2.7	4	1.0	0	14.8	16	4	\$565	0.296
1200x3000x400	1.0	4	3	4	1.0	0	16.0	16	4	\$598	0.320
1200x3300x400	1.0	4	3.3	4	1.0	0	17.2	16	4	\$631	0.344
1200x3600x400	1.0	4	3.6	4	1.0	2	20.4	24	6	\$781	0.408
1200x3900x400	1.0	4	3.9	4	1.0	2	21.6	24	6	\$814	0.432
1200x4200x400	1.0	4	4.2	4	1.0	2	22.8	24	6	\$847	0.456
1200x4500x400	1.0	4	4.5	4	1.0	2	24.0	24	6	\$880	0.480
1200x4800x400	1.0	4	4.8	4	1.0	2	25.2	24	6	\$913	0.504
1200x5100x400	1.0	4	5.1	4	1.0	2	26.4	24	6	\$946	0.528

- Timber Size will be 200x100 Macrocarpa Landscape Grade
- Planter will be two boards high = 400mm
- Holes will need to be drilled to allow fixing with coach screws.
- 200x100 will be cut to exact length and square
- Prices include gst