

## Patio Planter Boxes 515mm Wide x 420mm High

Planter Size

Width x Length x Height	End	No.	Side	No.	Floor	No.	Mid		Mid		50x50	100mm	Multigrip	Total	m3 or tonnes
							Brace	No.	Brace	No.	Packer	Screws			
							140x45		90x45		515mm				
515x600x420	425	6	600	6	505	3	425	0	425	0	2	28	8	\$224	0.048
515x900x420	425	6	900	6	805	3	425	0	425	0	2	28	8	\$272	0.065
515x1200x420	425	6	1200	6	1105	3	425	0	425	0	2	28	8	\$320	0.082
515x1500x420	425	6	1500	6	1405	3	425	0	425	0	3	30	8	\$369	0.099
515x1800x420	425	6	1800	6	1705	3	425	0	425	0	3	30	8	\$417	0.116
515x2100x420	425	6	2100	6	2005	3	425	2	425	1	3	42	12	\$513	0.139
515x2400x420	425	6	2400	6	2305	3	425	2	425	1	3	42	12	\$561	0.156
515x2700x420	425	6	2700	6	2605	3	425	2	425	1	3	42	12	\$609	0.173
515x3000x420	425	6	3000	6	2905	3	425	2	425	1	4	44	12	\$658	0.190
515x3300x420	425	6	3300	6	3205	3	425	2	425	1	4	44	12	\$706	0.207
515x3600x420	425	6	3600	6	3505	3	425	2	425	1	4	44	12	\$753	0.224
515x3900x420	425	6	3900	6	3805	3	425	4	425	2	4	56	16	\$850	0.246
515x4200x420	425	6	4200	6	4105	3	425	4	425	2	4	56	16	\$898	0.263
515x4500x420	425	6	4500	6	4405	3	425	4	425	2	5	58	16	\$947	0.280
515x4800x420	425	6	4800	6	4705	3	425	4	425	2	5	58	16	\$995	0.297
515x5100x420	425	6	5100	6	5005	3	425	4	425	2	5	58	16	\$1,043	0.314

- Timber Size will be 140x45 Dressed Macrocarpa cut to exact length
- Patio Planter will be three boards high - 420mm + 50mm packer = 470mm
- 6mm Pilot Holes will need to be drilled to allow fixing with 100mm long 14 gauge galvanised screws else splitting n
- Prices include gst