

## Patio Planter Boxes 515mm Wide x 700mm High

Planter Size

Width x Length x Height	End	No.	Side	No.	Floor	No.	Mid		Mid		50x50	100mm	Multigrip	Total	m3 or tonnes
							Brace	No.	Brace	No.	Packer	Screws			
							140x45		90x45		515mm				
515x600x700	425	10	600	10	505	3	425	0	425	0	2	44	16	\$357	0.074
515x900x700	425	10	900	10	805	3	425	0	425	0	2	44	16	\$426	0.099
515x1200x700	425	10	1200	10	1105	3	425	0	425	0	2	44	16	\$495	0.123
515x1500x700	425	10	1500	10	1405	3	425	0	425	0	3	46	16	\$565	0.148
515x1800x700	425	10	1800	10	1705	3	425	0	425	0	3	46	16	\$634	0.172
515x2100x700	425	10	2100	10	2005	3	425	4	425	1	3	66	24	\$790	0.208
515x2400x700	425	10	2400	10	2305	3	425	4	425	1	3	66	24	\$859	0.232
515x2700x700	425	10	2700	10	2605	3	425	4	425	1	3	66	24	\$928	0.257
515x3000x700	425	10	3000	10	2905	3	425	4	425	1	4	68	24	\$999	0.281
515x3300x700	425	10	3300	10	3205	3	425	4	425	1	4	68	24	\$1,068	0.306
515x3600x700	425	10	3600	10	3505	3	425	4	425	1	4	68	24	\$1,137	0.331
515x3900x700	425	10	3900	10	3805	3	425	8	425	2	4	88	32	\$1,293	0.366
515x4200x700	425	10	4200	10	4105	3	425	8	425	2	4	88	32	\$1,362	0.390
515x4500x700	425	10	4500	10	4405	3	425	8	425	2	5	90	32	\$1,432	0.415
515x4800x700	425	10	4800	10	4705	3	425	8	425	2	5	90	32	\$1,501	0.440
515x5100x700	425	10	5100	10	5005	3	425	8	425	2	5	90	32	\$1,570	0.464

- Timber Size will be 140x45 Dressed Macrocarpa cut to exact length
- Patio Planter will be five boards high - 700mm + 50mm packer = 750mm
- 6mm Pilot Holes will need to be drilled to allow fixing with 100mm long 14 gauge galvanised screws else splitting n
- Prices include gst